

## Knog PWR Rider Front Light



KNOG-12057

Peak brightness: 450 lumens  
Material: 30mm CNC Aluminium machined body  
Weight: 117g

Pack Quantity Piece  
Price : £57.99 inc VAT

### Overview

PWR Rider is a 450 lumen bike light that can also be used as a power bank. Includes the option to program your brightness and runtime (through ModeMaker app), then use your remaining battery to charge your devices. The light outputs in an elliptical beam for broader, brighter road coverage; has a 2 hr runtime at max 450 lumens and 4 smart battery indicator LEDs to let the rider know how much charge is left in the light.

### RUNTIME

| MODE         | LUMENS | RUNTIME |
|--------------|--------|---------|
| Ride         | 450    | 2hrs    |
| Commuter     | 190    | 5.5hrs  |
| Stamina      | 50     | 16hrs   |
| Pulse        | 320    | 7hrs    |
| Strobe Flash | 190    | 10hrs   |
| Eco-Flash    | 50     | 90hrs   |

### FEATURES

The two Charger lights come with 5 pre-programmed modes, just in case you haven't yet discovered the ModeMaker app. The PWR Rider will last 2 hours at 450 lumens, and for those with stamina, will run at 200 lumens for 5 hours.

- **Elliptical beam** - Elliptical beam for wide view works with spot beam for intense light in front of front wheel.
- **Programs your modes** - The ModeMaker app allows you to design the modes for any PWR bike light. Simply plug in your light, then select and tailor modes from the menu. You can do things such as control brightness, adjust runtimes and add new light modes.
- **Charge your devices** - Rear of the light is a USB rechargeable power bank. Use this to charge your phone, GoPro or cycle computer on the go. 1 hour riding @450 lumens means you can top up charge your iPhone by 35%. Charge time 3.5 hours.

## SPECIFICATION

- Light output: 450 Lumens.
- Power Bank: 2200 mAh.
- Dimensions: 122 x 30mm .
- Weight: 115g.
- Battery indicator.
- CNC Machined.
- Programmable modes.
- USB rechargeable.
- Water resistant when cap is on.

## INSTRUCTIONS

**Fitting your new light to your bike:** Place your light on the handle bar with knog logo on strap facing forward. There are two holes to choose from depending on your bar diameter.

**Using the button:** To turn on press and hold on/off button until the light turns on. To turn off press and hold the button until the light switches off. To change modes once the light is on, a short press of the button changes modes.

**Charging your lights:** PWR Commuter and PWR Rider use a micro USB input to charge. Find this under the end cap. Press RED button to release cap.

- ColourBlack
- DisciplineRoad
- FeaturesUSB chargeable